



Тумба ТВ 160 Пенни






















Прежде чем приступить к сборке, ознакомьтесь с памяткой на обороте



- | | | | |
|-----------|------------------------------------|-----------|--------------------------------|
| D | Montageanleitung | GB | Assembly instructions |
| FR | Notice de montage | IT | Istruzioni di montaggio |
| NL | Handlieding voor de montage | PL | Instrukcja montażu |
| CZ | Montážní návod | SK | Návod na montáž |
| HU | Szerelési útmutató | RO | Instrukțiuni de montaj |
| TR | Montaj talimatı | RU | Инструкция по монтажу |





№	Size/MaB (mm)	Qty	✓	№	Size/MaB (mm)	Qty	✓
1	425x383x50	2		11	490x208x18	1	
2	419x490x18	2		12	460x150x14	1	
3	1654x400x24	1		13	444x513x3	2	
4	425x373x18	1		14	469x342x3	1	
5	425x373x18	1		15	160x50x50	2	
6	494x373x18	1		16	160x50x50	2	
7	524x355x15	2		17	350x150x14	1	
8	1520x68x18	1		18	350x150x14	1	
9	1630x388x18	1		19	283x50x18	2	
10	1520x40x18	1		20	444x513x3	1	

1

A

030093



x12

C

230010

8x32



x20

H

160046



x2

K

250012

3.5x15



x12

O

180098



x4

The diagram illustrates the assembly of a cabinet door. It shows the door (3) being attached to the frame (1) using screws (A), pins (C), and brackets (O). Detailed insets show the correct alignment and fastening of the hinges (K) and pins (H). A warning section at the bottom left shows the correct way to insert a pin (C) into a hole, with a smiley face for correct and a sad face with an X for incorrect. Another inset shows a pin (C) being inserted into a slot.

3-7

2

A 030093
x24


C 230010
8x32
x8

D 210020
x2

F 030052
M4x22
x2

K 250012
3.5x15
x8




M 180096
x4




3

B 030110
x8

J 070017
30x30
x4



4



B

030110



x8

5


B

030110

x4



6




B

030110

x8



7

B 030110
x8



8

I 220043
x2



9

A 030093
x4


B 030110
x4

C 230010
8x32
x6

D 210020
x1

F 030052
M4x22
x1

L 250024
3.5x35
x2



- | | | | | | | |
|----|----------------------------|-------------------|-------------------|--------------------|------------------------------|----------------------------|
| 10 | E
030043
M4x10
x2 | G
190002
x8 | V
180080
x1 | V1
090004
x1 | V2
250012
3.5x15
x1 | V3
250044
4x40
x1 |
|----|----------------------------|-------------------|-------------------|--------------------|------------------------------|----------------------------|

